



**nokian
HEAVY TYRES**

New

Tire Pressure LED

Easy tyre pressure check available on all Nokian tyres

How to use

- First adjust the tyre pressure to the recommended value.
- Screw the Tire Pressure LED tight by hand, using the anti-theft tool provided with the kit.
- The Tire Pressure LED is now calibrated and is constantly monitoring the tyre pressure.

What to do when LED starts flashing

- Unscrew the Tire Pressure LED with the anti-theft tool.
- Adjust the tyre pressure to the recommended value.
- Reinstall the Tire Pressure LED.

Benefits

- Constant pressure control.
- No need for regular pressure gauge checks anymore.
- The led indicates the need for pressure adjustment.
- Increase in tyre and tube lifespan due to right operating pressure.
- No more tyre break-ups due to running tyres underinflated.

Technical properties

- Led activated when a drop from the calibrated value exceeds 0.6 bar (forestry tyres).
- Battery used only when led is activated (pressure drop).

- › Easy to use
- › Reduces tyre maintenance
- › Reduces tyre break-ups
- › Saves money



Trust the Natives.
www.nokiantyres.com/heavytyres